

Installation Guidelines

In addition to the details below all relevant works should be carried out according to the 'Plumbing and Drainage Code of Practice' and the requirements of any relevant statutory body.

- During the framing and rough in stages of construction ensure that there are sufficient fixings for the mounting of the vanity cabinet. There should be at least two vertical studs for fixing provided not more than 100mm from each edge of the cabinet.
- The solid back of the cabinet must not be damaged, removed, cut or drilled more than is necessary for the access of the plumbing pipes.
- During installation the cabinet should be fixed with screws suited to the stud material and with a pan or counter sunk head.

While every effort is made to supply our clients with outstanding quality products, Timberline Bathroom Products can in no way be held responsible for any damages arising from failure due to the method in which the vanity was installed or commissioned.

